

## DS-abrMCbl



Step 1:

Picture ① shows original car seat without power socket.

Picture ② shows original power socket devices to install in car seat.



Step2:

First take the back cover of the original car seat out, make the leather seat covers to the headrest place, cut the same size of original power socket under the headrest place(about 50mm). Then put the power socket main part in the crossbeam place of the back seat. Finally put down the leather seat cover to the back seat and cut the hole of the power socket, make the rest leather to cover the hole place. (Note: using the sharp devices to cut the hole place, pay attention not to scratch the original car seat and other positions).



### Step3:

Put the socket cover into the main part of power socket on the back seat, then settle the power cable and fix the cable with tape, connect power cable to car power source. Put the back cover of the original seat back. Finally put the car headrest to the original place.



Installation effect photos show as below:

After finishing installation, put the Android headrest monitor to the power socket, then the Android headrest monitor could power on to use.

